

Lathe Maintenance Schedule

LAST UPDATED: 04/14/2023

Lathe Maintenance Schedule

Keep your Haas machines running at peak performance while avoiding unplanned downtime. A maintenance program allows you to manage your schedule rather than getting caught with untimely surprises. This page shows the recommended maintenance intervals.

III DOWNLOAD LATHE MAINTENANCE CHECKLIST

Lathe - Maintenance Schedule

Auxiliary Filter	
Maintenance Item	Interval
Replace the filter bag.	Check the Gauge
Inspect the hoses for cracking.	Six Months
Axis Lubrication	
Maintenance Item	Interval
Inspect grease reservoir level.	Monthly
Inspect the hoses for cracking.	Six Months
Perform an Axis Lubrication Test.	Six Months
Ballscrews/Linear guides equipped with zerk fitting	Monthly or weekly if cutting absorbent materials
Electrical Cabinet	
Maintenance Item	Interval
Clean vector drive air vents / filter.	Monthly
Enclosure	
Maintenance Item	Interval
Inspect window for damage.	Daily
	Daily
Inspect the door interlock operation.	Bully

Gearbox			
Maintenance Item	Interval		
Inspect the oil level.	Monthly		
Replace the oil.	Annually		
Oil Skimmer			
Maintenance Item	Interval		
Inspect the oil skimmer pickup tube.	Six Months		
Pneumatics			
Maintenance Item	Interval		
Inspect the spindle air regulator pressure.	Weekly		
Inspect the hoses for cracking.	Six Months		
Clean the Air Purge Solenoid.	Annually		
Probe System			
Maintenance Item	Interval		
Check probe calibration.	Six Months		
Standard Coolant System			
Maintenance Item	Interva	al	
Clean the filter screen.	As Requ	uired	
Inspect the coolant level.	Weekly		
Inspect the coolant concentration. Fill out the Mixture -	Maintenance Log sheet. Weekly		
Completely clean the coolant tank and replace the cool	ant. Six Mor	nths	
Verify coolant refill is operating correctly.	Six Mor	nths	
Inspect turret coolant lines for chips.	Monthl _:	y	
High Pressure Coolant (HPC) 300/1K PSI			
Maintenance Item	Interval		
Clean the HPC-300 / 1K Pump Filter	Six Months	Six Months	
Inspect the hoses for cracking.	Six Months	Six Months	

04	Lathe Maintenance Schedule	
Verify the Auto Clean system is operating correctly.	Six Months	
Spindle Lubrication		
Maintenance Item	Interval	
Inspect lubrication tank level.	Monthly	
Perform Spindle Lubrication Test.	Six Months	
Hydraulics		
Maintenance Item	Interval	
Clean chips from the coolant collector.	Weekly	
Inspect the oil level.	Monthly	
Change the Hydraulic fluid	Every 2 years or as needed per conditions	
Replace the oil filter - Parker Hydraulic Unit.	Annually	
Replace the oil filter - Rexroth Hydraulic Unit.	Annually	
Replace the oil filter - Haas Hydraulic Unit - SL.	Annually	
Tailstock		
Maintenance Item	Interval	
Grease the tailstock.	Monthly	
Inspect the reservoir grease level.	Monthly	
Chucks		
Maintenance Item	Interval	
Grease the chuck jaws.	Weekly	
Chuck Multi-Point Inspection.	Six Months	
Clean the Chuck	Annually	
Barfeeders		
Maintenance Item	Interval	
Grease the bar feed push rod and bushing.	Weekly	
Grease the ballscrew, V-roller tracks, and rotation. (Bar	300) Monthly	

Check belt tenstion. (Haas Barfeeder)

Annually

Check push rod alignment.

Six Months