

20 - Lathe - Maintenance

# Lathe -Interactive Service Manual

#### 20.1 LATHE - MAINTENANCE SCHEDULE

- 1 Lathe -Introduction
- 2 Lathe -Specifications
- 3 Lathe -Installation
- 4 Lathe Spindle
- 5 Lathe C-Axis
- 6 Lathe Turret Indexer Assembly
- 7 Lathe Live Tooling
- 8 Lathe -Hydraulic Power Unit (HPU)
- 9 Lathe -Tailstock
- 10 Lathe Sub-Spindle
- 11 Lathe -Probing
- 12 Lathe Parts Catcher
- 13 Lathe Axis Motion
- 14 Lathe -Lubrication 'tems
- 15 Lathe -Electrical Control

16 - Lathe - Chip Removal and Coolant

17 - Lathe -Workholding

18 - Lathe - Auto Door

19 - Lathe -Enclosure

### 20 - Lathe -Maintenance

21 - Lathe -Applications

22 - Lathe -Automatic Parts Loader (APL)

23 - Lathe - Haas Bar Feeder

24 - Lathe - Haas Robot Package

## 20.1 LATHE - MAINTENANCE SCHEDULE

## Lathe - Maintenance Schedule

Auxiliary Filter		
Maintenance Item	Interval	
Replace the filter bag.	Check the Gauge	
Inspect the hoses for cracking.	Six Months	
Axis Lubrication		
Maintenance Item	Interval	
Inspect grease reservoir level.	Monthly	
Inspect the hoses for cracking.	Six Months	
Perform an Axis Lubrication Test.	Six Months	
Ballscrews/Linear guides equipped with zerk fitting	Monthly or weekly if cutting absorbent materials	
Electrical Cabinet		
Maintenance Item	Interval	
Clean vector drive air vents / filter.	Monthly	
Enclosure		
Maintenance Item	Interval	
Inspect window for damage.	Daily	
Inspect the door interlock operation.	Daily	
Inspect waycovers and lubricate.	Monthly	
Gearbox		
Maintenance Item	Interval	
Inspect the oil level.	Monthly	
Replace the oil.	Annually	
Oil Skimmer		
Maintenance Item	Interval	
Inspect the oil skimmer pickup tube.	Six Months	
Pneumatics		
Maintenance Item	Interval	
Inspect the spindle air regulator pressure.	Weekly	
Inspect the hoses for cracking.	Six Months	
Clean the Air Purge Solenoid.	Annually	

Maintenance Item	Interva	ı
Check probe calibration.	Six Mon	-
Standard Coolant System		
Maintenance Item		Interval
Clean the filter screen.		As Require
Inspect the coolant level.		Weekly
Inspect the coolant concentration. Fill out the Mixture	e - Maintenance Log she	et. Weekly
Completely clean the coolant tank and replace the coolant.		Six Months
Verify coolant refill is operating correctly.		Six Months
Inspect turret coolant lines for chips.		Monthly
High Pressure Coolant (HPC) 300/1K PSI		
Maintenance Item		Interval
Clean the HPC-300 / 1K Pump Filter		Six Months
nspect the hoses for cracking.		Six Months
Verify the Auto Clean system is operating correctly.		Six Months
Spindle Lubrication		
Maintenance Item	In	iterval
Inspect lubrication tank level.	М	onthly
Perform Spindle Lubrication Test.	Si	x Months
Hydraulics		
Maintenance Item	Interval	
Clean chips from the coolant collector.	Weekly	
Inspect the oil level.	Monthly	
Change the Hydraulic fluid	Every 2 years or as needed per conditions	
Replace the oil filter - Parker Hydraulic Unit.	Annually	
Replace the oil filter - Rexroth Hydraulic Unit.	Annually	
Replace the oil filter - Haas Hydraulic Unit - SL.	Annually	
Tailstock		
Maintenance Item		Interval
Grease the tailstock.		Monthly
Inspect the reservoir grease level.		Monthly

Maintenance Item	Interval
Grease the chuck jaws.	Weekly
Chuck Multi-Point Inspection.	Six Months
Clean the Chuck	Annually
Barfeeders	
Maintenance Item	Interval
Grease the bar feed push rod and bushing.	Weekly
Grease the ballscrew, V-roller tracks, and rotation. (Bar 300)	Monthly
Check belt tenstion. (Haas Barfeeder)	Annually
Check push rod alignment.	Six Months